


1. Name and Parts



- | | |
|--------------------------|---------------------|
| 1. Power on / off Switch | 5. Reset Key |
| 2. Video / Audio Mode | 6. USB Slot |
| 3. Format Key | 7. LED Indicators |
| 4. Memory Card Slot | 8. Vibration On/Off |
| | 9. Camera Lens |

*Warranty will be void if the serial number sticker is tampered.


2. Package Content

- ① Quick Guide ② Memory Card ③ USB Cable



1

3. Charge Battery & Insert Memory Card



Plug the micro USB end of cable into USB port (6) and plug the other end to an USB power source. After charging, with golden contact facing down, insert the memory card into the card slot (4). Then the device will be ready for further operations.

Note: Device cannot be powered on when no card is inserted.

- Solid green LED - Charging
- Green LED goes off - Fully charged
- Blinking blue LED - Low battery

4. Using your Own Power Bank



Connect the micro USB end of cable into USB port (6) and plug the other end to a power bank of your choice. The power bank can be used as an extra battery.

2

5. Format Memory Card

- (1) Press and hold format key (3), and then power on the device by switching the Power switch (1) to **On**.
- (3) You will see blue LED will be on and red LED flashes.
- (4) When device powers off itself, the format is complete.

6. LED Indicators

- Solid blue LED ■ - Power on
- Solid red LED ■ - Recording on
- Blinking red LED ■ - No card inserted / Card full
- Solid green LED ■ - Charging

7. Operation

Power on - With memory card inserted, switch (1) to **On**.

Power off - With memory card inserted, switch (1) to **Off**.

Video Recording - Power on the device ; switch (2) to **Video** to start recording.

Audio Recording - Power on the device ; switch (2) to **Audio**.

Standby Mode - Power on the device and switch (2) to **Mode**. If the device has no operation for 3 mins, it powers off itself.

Reset - When the device is functioning abnormally, press (5) once to reset it.

Note: Device powers off itself after 3 mins in no operation standby mode.

3

8. Date & Time Setting (for Windows System)

- (1) From the desk top right-click to open Notepad, create a text (.txt) file named **settime.txt**
- (2) On the first line of the file, enter date and time information as year.month.day hours.minutes.seconds. For example, suppose the time is April 20th, 2017 15:00. Then, please enter 2017.04.20 15:00:00

Note: There should be a space left between date and hour; time format should be the 24-hour format.

- (3) Save the file to the root directory of the memory card.
Note: If the setting is completed, the settime.txt file will not be visible when you connect the device to the computer again.

9. Vibration Alert

- Power on / off - Vibrates once
- Start / Stop Video Rec - Vibrates once
- Start / Stop Audio Rec - Vibrates twice

10. Download the video to PC

- (1) Make sure the memory card is inserted into the device.
- (2) Power on the device and connect the device to the PC with the USB cable.
- (3) The card will be recognized as an external drive on the PC. And you could start to retrieve files from the card.


4

11. Specification

Built-in Camera Module	
Built-in Image Sensor	1/4" progressive CMOS sensor
Sensor Resolution	1280X960
Sensor Sensitivity	3.3 Lux@F 2.8
Lens F/No.	F 2.8
Focal Length	3.7mm
Angle of view	67°
Video Spec.	
Algorithm	H.264
File Format	AVI
Video Recording Mode	Manual
Recording Capability	1280x720
Frame Rate	Up to 30 fps
Audio Spec.	
Algorithm	WAVE
File Format	WAV
Storage & I/O	
Memory Type	Micro SD Card (Support SDHC max. 16GB)
Data Interface	Micro USB 2.0
Misc.	
Date/Time Table	YYYY.MM.DD HH:MM:SS
Power	
Power Input	DC 5V
Power Consumption	(Video)220mA-260mA / (Audio)140mA
Charging Time	120min(600mA)
Battery Input	DC 3.7V / 750mA polymers battery (XK502071)
Battery Lifetime	Continuous video recording 140min ; Audio recording 280min
Recording Time	1280x720(A file/1.6G/30min)/Audio(A file/38M/30min)
Physical	
Vibration Alert	Power on/off, Recording, Low battery
Dimension	95x50x10 mm
Weight	39g

5

PV-BC10 720p Business Card Type DVR / Audio Recorder



LawMate, innovation never stops

LawMate[®]

V1.0